

## STANDARD FRAME HINGE & STRIKE LOCATIONS

ICI #	HIEGHT	A	B	C	D	Z
M80	80"	5	35-1/4	65-1/2	N/A	42
M84	84"	5	37-1/4	69-1/2	N/A	46
M94	94"	5	29-13/16	54-5/8	79-7/16	56
M96	96"	5	30-1/2	56	81-1/2	58
M100	100"	5	31-13/16	58-5/8	85-7/16	62
M106	106"	5	33-13/16	62-5/8	91-7/16	68
M118	118"	5	38-1/2	72	105-1/2	80

### NOTES

1. STRIKE MEASUREMENT IS FROM TOP OF FRAME HEADER TO CENTERLINE OF STRIKE.
2. HINGE MEASUREMENTS ARE FROM TOP OF FRAME HEADER TO TOP OF HINGE CUTOUT.
3. ICI WILL ACCOMMODATE ANY HINGE OR STRIKE LOCATION.
4. ALL MUESUREMENTS ARE IN INCHES.

## ROUGH OPENINGS

	<u>WIDTH</u>	<u>HEIGHT</u>
Door Frame	+ 1-1/4"	+ 1"
<u>500/600 Series</u>		
D/F with Sidelight (Flush Stud)	+ 3-1/8"	+ 1"
D/F with Sidelight (Inverted Stud)	+ 2-3/4"	+ 1"
Borrowed Light (Flush Stud)	+ 1-1/2"	+ 1-1/2"
borrowed Light (Inverted Stud)	+ 1/4"	+ 1"