



# Mitered Door Frame Installation



www.aluminum-frames.com  
 info@aluminum-frames.com

## Door Frame Installation

- 1) Install the vertical jamb legs (trim if ordered with scribe).  
**ONLY CUT THE BOTTOM OF FRAME.**  
 \* only cut top of frame if installing a transom and frames are clearly marked not to cut the bottom.
- 2) Install the header and insert the chevron 45° clips and attach with 1/2" tek head self tapping screws.
- 3) Plumb the hinge jamb leg and screw in place.
- 4) Hang the door and use it to adjust the strike leg to ensure an even gap for door clearance. Screw into place.
- 5) A 20 Minute fire rated frame requires 1-5/8" drywall screws 8" on center around the perimeter of the frame on both sides.

### Rough Opening + 1-1/4" Wide x 1" height

Example - 3'0" x 7' 0" door frame R/O = 37-1/4" x 85"

Customer:
Project:
Location:
Date: